

6-3. Initialization

Items to initialize

The following items must be initialized for normal system operation:

Item	When to initialize	Reference
Engine oil maintenance data	After changing engine oil	P. 556
Tire pressure warning system	When changing the tire inflation pressure by changing traveling speed	P. 565